

## Installing the Interface

REV 281117

Follow the instructions below to install the FT-RC-RN kit.

Turn on the car ignition and the radio (Media NAV). Then, plug the device to the vehicle's OBD connection (usually found inside the glove compartment).

Once you plug in the device to the OBD connection, wait for the device to program the rear camera and reset the radio. After the radio has been reset, you can unplug the device and hand it over to the costumer, in case he needs to enable the rear camera once again.



Once you have programmed the rear camera, remove the radio. Then, connect the whip to the Camera Entry, ACC Output, GND Output and the Reverse Entry connections.

See on the figure below the description of each one of the wires on the whip.



## Functioning

Once you finish installing, test the system functions.

Turn on the ignition, wait for the radio to start and put the car on the reverse gear to view the rear camera image.

If that does not work, check the device installation and follow all the instructions on this manual again.



NAV Media after installing the rear camera.